


L98 1987-89

Wiring Diagram - 5.7L "Y" Series

Figure 1 of 4




4-4-86
*6S 2504-6E

L98 1987-89

Wiring Diagram - 5.7L "Y" Series


Figure 2 of 4



L98 1987-89

Wiring Diagram - 5.7L "Y" Series


Figure 3 of 4



L98 1987-89

Wiring Diagram - 5.7L "Y" Series

Figure 4 of 4



* 75 3282-6E
10-9-86